





 USER MANUAL	Product Description  — 1 —	How to reset camera: When the camera is turned on, hold on the reset button for about 3 seconds until you see the red light and blue light alternately flashing slowly, and then the blue light flashing slowly or keep on. Device Description • This device has two modes: AP mode and WiFi mode. • Built-in battery. • Support DCSV2A power supply. Indicator Status — 2 —	Yellow light: always bright during charging. Blue light: AP mode,slow flash---recording; keep on---stop recording Red light: WiFi mode,slow flash---recording; keep on---stop recording Restore factory: The red light and blue light alternately flashing slowly Step 1: Pre-Setup ☒ Long press the reset button 3 seconds to reset. — 3 —	☒ It's recommended to place the camera within 2 meters of the router for the first time connecting to the Internet. ☒ Connect the mobile phone to the router Wi-Fi, and know the Wi-Fi connection password. (Only 2.4GHz Wi-Fi is supported) (How to power off: Long press the power button for 3 seconds to power off) Step 2 : APP Download and Registration  — 4 —	1 Search for "Fowl" in App Store or Google Play, or scan the QR code to download the app.  2 Click "Register", enter the user name and password to complete the registration.  Step 3: Add Devices to the APP Method One: AP Connection — 5 —	1 Please go to your mobile phone WiFi Settings, select the WiFi hotspot that start with OK-XXX and connect it.  2 Open the app and Click play to watch and operate the camera.  — 6 —	Configure WiFi 1 Enter camera parameters  2 Select WiFi settings  3 Select your home WiFi and enter the WiFi password correctly.  — 7 —	Method Two: Sonic Connection 1 Click Add device and choose WiFi camera.  2 Please enter the correct WiFi password. (The device does not support 5G Hz network).  — 8 —	1 About 20 seconds later, you will be prompted for a successful binding.  2 Click "Bind now".  — 9 —	Device Share   — 10 —	Click "Settings" on the right corner, then select "Device Share"--- "QR Code Sharing". Other users can open the app and click the "+" in the upper right corner of the home page to scan the QR code to add the device. Dedicated PC Video Player  — 11 —	Download dedicated video player for playing Micro SD card video: For Win: https://www.cookycam.cn/download/VideoPlayer.exe For Mac: https://www.cookycam.cn/download/VideoPlayer-Mac.dmg If any questions, please feel free to contact our customer service. Thank you! — 12 —
---	---	---	--	---	---	--	---	--	---	---	---	---